

Kovanie na WC kabíny

UPEVNENIE TRUBKY CS-F30



990060490

**TRUBKA PREPOJOVACIA 32MM
CS - S32 NEREZ 6M**



990060491

**ZÁMOK S INDIKÁTOROM OBSADENÉ-
VOLNÉ 1370CO - L5500 NEREZ**



990060501

**SPOJ TRUBKY ROHOVÝ CS - 80
NEREZ 90ST**



990060494

**SPOJKA TRUBKY VT - T70
NEREZ**



990060496

**ZÁVES NA KABÍNKY CT - H70L
NEREZ**



Ľavý: 990060493

Pravý: 990060495

**NOHA REKTIFIKAČNÁ VS - U0000
UNIVERZÁLNA NEREZ**



990060498

**ÚCHYTKA DO DVERÍ H380
NEREZ**



990060500

**UHOLNÍK KABÍNKY PRICHYTENIE
K STENE VS - BL450 NEREZ**



990060497

**DORAZ NA DVERE CS - S49
NEREZ**



990060492

**SKRUTKY/ZÁMOK
1371CO-L55/18,M4/30**



990060502

**SKRUTKY ZÁVES NA KABÍNKY
CT - H70 / 18**



990060503

Obrázky sú ilustračné.